Clear Memory Mode

BRAKE VACUUM CONTROL(BVC) (DIAGNOSTICS)

9. Clear Memory Mode

A: OPERATION

For details concerning DTC clear operation, refer to "Subaru Select Monitor". <Ref. to BVC(diag)-11, Subaru Select Monitor.>